VERSION 1 USER MANUAL

Mobile App for Height Adjustable Desks



0° T*i* motion

Contents

1.	Pref	face	3
2.	Safe	ety Instructions	4
	2.1	Abnormal operation	
	2.2	Out of range reminder	5
3.	Blue	etooth device	6
	3.1	Built-In Control Boxes-TC15P/ TC15S	
	3.2	Wireless Dongle-TWD1	6
4.	Dow	nload the "STAND UP PLS"	10
5.	Parii	ng Bluetooth and get started	11
	5.1	Introduction page	11
	5.2	Register your profile	
	5.3	Connection	
	5.4	Program settings	14
6.	. Operation		17
	6.1	Buttons Introduction	17
7.	Men	nory Positions	18
8.	Histe	ory Tracking	19
9.	Setti	ings	20
	9.1	Disconnection to this desk	21
	9.2	Connect to alert	
	9.3	Reset tracking	23
	9.4	Change program	24
	9.5	Change profile	25
	9.6	Reset the desk	
10.	Erro	r Codes	27
11.	Disp	oosal Guidance	29
12.	TiM	OTION Application Policy	

1.Preface

T<mark>;</mark> MOTION

We are delighted that you have chosen products from TiMOTION. Our ergonomic height adjustable workstation systems are high-tech products based on many years of experience in the manufacture and development of electric linear actuators, electronic control boxes, hand controls, and power supplies. We are constantly improving our products to meet and exceed customer expectations.

This User Guide will tell you how to install, use and maintain your Ergo Motion products. We are sure these products will provide you with many years of reliable operation. All TiMOTION products undergo rigorous functionality and quality testing prior to shipping. You are always welcome to contact our local corporate offices or sales agents for any questions you may have. It is our goal and pleasure to assist you.

The Mobile App, "STAND UP PLEASE," is developed by TiMOTION and allows the end users to control their height adjustable desks via their mobile devices.



2.Safety Instructions

2.1 Abnormal operation

If the users accidently use two fingers on the mobile device screen, the columns of the height adjustable desk might be moved up or down automatically. In order to prevent any accidents, there will be a pop-up message shown on the screen as below.

••••	中華電信 4G	下午2:16	@ -7 @ \$ 🔲 ·
20			~
		(!)	
	Abno	rmal ope	ration
Þ	Please re	emove your your screen	finger on
		DISMISS	
			i
			\sim



2.2 Out of range reminder

The below pop-up message will give the users a reminder that their fingers need to stay in the range of the buttons, or else it may not respond properly.





3.Bluetooth device

We provide two options of Bluetooth devices: a built-in control box or a wireless dongle for users to choose from.

3.1 Built-In Control Boxes-TC15P/ TC15S

The Bluetooth functionality is installed into two of our ergonomic control boxes: the TC15P and TC15S.



3.2 Wireless Dongle-TWD1

The TWD1, designed as an adapter with Bluetooth functionality, allows the users to control their desk height remotely via their "STAND UP PLEASE" app.





Compatibility:

The TWD1 is compatible with the following ergonomic control boxes and hand controls:

Picture			
Control Box	TC11	TC15	TC16

Picture		□ 8 8 ∧ ∨ 1 2 3 4 M	0% T/MOTION
Control	TDH5PR	TDH6PR	TDH8

Picture			088 gê ineraa
Control	TDH8D	TDH9P	TDH11P

Picture			
Control	TDH12P	TDH13P	TDH14P



Picture		+ -	0% Trimotion
Control	TDH15	TDH16	TDH17

Picture	
	888 ▲ 1 ↔ g8 r.morren ♥ 2 ↔
Control	TDH18P



How to connect the TWD1, control box and hand control:



norrom **i**t **o**

4. Download the "STAND UP PLS"

The Mobile App, "STAND UP PLS," is free on iOS or Android App store. You can scan the following QR codes to download the app onto your device.



Android



iOS



STAND UP PLS



5. Paring Bluetooth and get started

5.1 Introduction page



Version 1 · 2018



5.2 Register your profile

In order to have calories consumption details, users need to input all the required information on the profile page as shown below:

Get Started				
Please register your profile				
SEX				
မှို FEMALE	සි MALE			
AGE Please enter you				
MEASUREMENTS				
IMPERIAL	METRIC			
WEIGHT Weight kg HEIGHT Height cm				
\rightarrow				



5.3 Connection

The users can place their phones in the middle of the table top, click the arrow sign, and the screen will display all the Bluetooth devices that the "STAND UP PLEASE" app detects. The strongest signal should show up in the very first one.

In order to avoid the signal interference, there will be Bluetooth signal number shown on the control box or the wireless dongle-TWD1, which can help the users choose the right signal number from the screen.

When searching, all the devices will be named as "stand UP" followed by a four-digit number.

Place your phone in the middle of your own table top and press to connect	Place your phone in the middle of your own table top and press to connect	Place your phone in the middle of your own table top and press to connect
* •	Bluetooth Device stand UP- 0916 CANCEL	Connecting to desktop
		DISMISS
\rightarrow	\rightarrow	\rightarrow



5.4 Program settings

When the Bluetooth connection succeeds, the screen will display the program setting page where users can select their own programs based on their preferences. Furthermore, they can create/customize their own program.

There will be four different programs for users to choose from: Beginner, Intermediate, Advanced, or Create Program.

Get Started	SKIP	
Choose your program		
்ர BEGINNER	77 CAL / H	
🐵 INTERMEDIATE	85 CAL / H	
advanced	93 CAL / H	
+ CREATE PROGRA	м	
\rightarrow		

08 T*i* MOTION

Each program will have a preset setting which cannot be altered except for the "Create Program" (as shown below).



noi tomⁱt <mark>30</mark>

If users would like to customize their own program, just press "Create Program".

- Step 1: Input the program name that you'd like to have.
- Step 2: Simply move the finger to change the sitting and standing time on the screen.
- Step 3: Press "Create" to save the changes.





6.Operation

6.1 Buttons Introduction





7.Memory Positions

There are two preset memory positions: 68cm/118cm.

If users would like to change the number (height), press Up or Down button to move the desk to the desired height first; then, tap the number on the screen, move and release it to the memory position (triangle sign on the left).





8. History Tracking

Users may track their standing and sitting time on a daily, weekly, or monthly basis. The data will display how many calories are consumed, equivalent to the running distance.



<mark>0</mark>8 T*i* MOTION

9.Settings

Press the top left icon to access the settings page.





9.1 Disconnection to this desk

If users wish to disconnect the desk, just press this button as indicated in the left picture shown below. If users want to reconnect the desk, please follow 5.3-connection.

e top

← Settings	
Disconnect to this desk	Place your phone in t middle of your own tab and press to conne
Connect to alert	
Reset tracking	- -
Change program	 ↓
Change profile	
Reset the desk	
	\rightarrow



9.2 Connect to alert

T<mark>i</mark>motion

Alert refers to the toning sounds that remind the users when to stand if they set up the programs. Two modes of alert sound: on or off. Users can mute the alerts by turning the button to "OFF" mode.

← Settings	C Settings
Disconnect to this desk	Disconnect to this desk
Connect to alert	Connect to alert
Reset tracking	Reset tracking
Change program	Change program
Change profile	Change profile
Reset the desk	Reset the desk



9.3 Reset tracking

If users would like to remove the tracking records, they can access the "Reset tracking" page to delete all the records.





9.4 Change program

Users may change the program according to their needs. Please refer to 5.4- program settings for the details.

Change program	← Settings
⊚j≇ BEGINNER 78 CAL / H	Disconnect to this desk
😂 INTERMEDIATE 86 CAL / H	Connect to alert
م ADVANCED 94 CAL / H 🗸	Reset tracking
+ CREATE PROGRAM	Change program
Ergonomically correct posture can prevent	Change profile
physical disconfort and even improve the concentration and efficiency. The advisable allocation of posture over a working day can be defined as: 60 % dynamic sitting 30 % working	Reset the desk
in a standing position 10 % walking around for meetings, copying etc.	



9.5 Change profile

Refers to 5.2-Register your profile.



9.6 Reset the desk

T; MOTION

If users would like the desk to go back to the default setting, they can click this button. After accessing the following page, press the "RESET" button until the desk descends to the lowest height and emits a beeping sound, which indicates the desk has returned to the default position.





10. Error Codes

There are seven error codes indicating problems and likely solutions:



<mark>08</mark> T*i* MOTION





11. Disposal Guidance

TiMOTION's control boxes and wireless dongles may be disposed of by dividing the components into different waste groups for recycling or combustion. We recommend that the control box or wireless dongle be disassembled as much as possible before disposal. The main groups to sort for waste are: plastic, cable scrap, combustible material and collection for recoverable resources.

The chart below shows the recycling groups in which the different components of the TC and TWD1 series should be placed into:

Products	Components	Recycling group
Control box	Plastic housing	Plastic recycling or combustion
	Cable	Cable scrap or combustion
	Transformer	Electronics scrap
Wireless dongle	Plastic housing	Plastic recycling or combustion
	PCB boards	Electronics scrap



12. TiMOTION Application Policy

The purpose of the application policy is to define areas of responsibilities in relation to applying a TiMOTION product defined as hardware, software, technical advice, etc. related to an existing or new customer application.

TiMOTION products as defined above are applicable for a wide range of applications within the Medical, Furniture, Ergonomic and Industrial areas. Yet, TiMOTION cannot know all the conditions under which our products will be installed, used, and operated, as each individual application is unique.

The suitability and functionality of the TiMOTION product and its performance under varying conditions (application, vibration, load, humidity, temperature, frequency, etc.) can only be verified by testing, and shall ultimately be the responsibility of the TiMOTION customer using any TiMOTION product.

TiMOTION shall be responsible solely for the compliance of our products according to the specifications set out by TiMOTION. It shall be the responsibility of the TiMOTION customer to ensure that the specific TiMOTION product can be used for the application in question.